INNENKOTFLÜGEL

Inner wing | Guardabarros interior | Garde-boue intérieur| Parafango interno

Artikel Nr.: **40821-102**





Schieben Sie den Wunderlich Innenkotflügel mit der markierten Fläche an den originalen BMW Kotflügel. Zuletzt Innenkotflügel mittels Schraube M6 x 30 fixieren.
Wir raten davon ab, unsere Hinterradabdeckung mit groben Stollenreifen zu kombinieren. Hier kann es unter Umständen zu Beschädigungen an der Abdeckung/dem Reifen kommen. Wir übernehmen keine Haftung für eventuell daraus entstehende Schäden.
Move the Wunderlich inner fender with the marked area to the original BMW fender. At last fix inner fender via M6 x 30 screw.
We do not recommend to use or combine the rear hugger together with massive bar (Offroad) tires like TKC80. It ispossible that the tire or the hugger will be damaged when using these tires together with the hugger. We accept no liability for any damages resulting.

Wunderlich GmbH I Joseph-von-Fraunhofer-Str. 6-8 I DE-53501 Grafschaft-Ringen I info@wunderlich.de I www.wunderlich.de I Tel.: +492641-3082-0