MOTORCYCLE STYLING - BMW R NINET

Racing Lines Series | Style Sport

Tank Top

SIG-1017-BMW RnineT UrbanGS GS Lines Red Styling Stickers

RACING LINES Series styling kit gives to your motorcycle a unique and sport character.

Product Information

Fits Model	BMW R NineT Urban GS 2016+ Model Year
Material Specifications	Cut Contour	Premium Quality Cast Vinyl	Gloss Finishing	Waterproof	Colour fade-proof
Installation	Easy	Dry application	Cut to Size - No trimming necessary	No need to remove any parts
Area Coverage	This kit comes in multible pices	The original paint colour around the stickers will remain visible
Installation Videos	www.signaturecd.com / Select from Home Page: Help Desk - Installation videos / General Products Playlist
Colours	Red Gloss

DRY APPLICATION INSTRUCTION

> Read the product installation instructions carefully before attempting installation.
> Product installation instructions are included with each product.
> Make sure hands are carefully clean before beginning installation.
> **Clean the surface with 70% alcohol**
> Ideal installation temperature: 15-35 degrees Celsius (60-90 degrees Fahrenheit).
> Avoid installing in direct sunlight or in windy conditions.
> Be sure that you made the correct sticker positioning.
> Use the heat gun or the hair dryer from a descent distance (15cm)
> With the heat gun remember if your fingers are burnt then the vinyl will burn also.

Tools you need
> A soft squeegee or a soft microfiber cloth over a credit card or a squeegee.
> A 70% alcohol for cleaning the desired installation area.
> Heat Gun
> Paper Tape
> Scissors

WET APPLICATION INSTRUCTIONS

> Read the product installation instructions carefully before attempting installation.
> Product installation instructions are included with each product.
> Make sure hands are carefully clean before beginning installation.
> **Clean the surface with 70% alcohol.**
> Always wet your fingers before handling the adhesive side of the film. Touching the adhesive side of the film can cause permanent and visible marks.
> **Keep both sides of the film wet during installation.**
> **Always use a soft squeegee or a soft microfiber cloth over a credit card or squeegee. in order to not cause any permanent scratches during application.**
> Do not put too much pressure during the squeegee strokes in order to not cause any permanent scratches.
> Be certain that all squeegee strokes overlap each other in order to avoid trapped water bubbles.
> Ideal installation temperature: 15-35 degrees Celsius (60-90 degrees Fahrenheit).
> Avoid installing in direct sunlight or in windy conditions.
> Use the heat gun or the hair dryer from a descent distance (15cm).
> With the heat gun remember if your fingers are burnt then the vinyl will burn also.

Tools you need
> A soft squeegee or a soft microfiber cloth over a credit card or a squeegee.
> A 70% alcohol for cleaning the desired installation area.
> Johnson's baby Shampoo. (On a spray bottle add 5% of shampoo or one drop per 100ml. and fill it up with water).
> Heat Gun

STICKERS REMOVAL INSTRUCTIONS

> With the heat gun or hairdryer, heat the desired sticker in order to soften the adhesive.
> When the sticker is warmed up, with your finger starting from an edge of the sticker, start to peel it off at a 45 degrees angle.
> **ATTENTION: If you feel resistance from the sticker while you try to peel it off, apply a bit of heat with the same method mentioned above.**
> Once the sticker is removed completely, if there is some adhesive left over, clean it using a microfiber cloth with alcohol.
> Make sure you do not rub the area too hard or you might blur the clear coat of the paint.

Tools you need
> A clean soft microfiber cloth.
> A 70% alcohol for cleaning excess adhesive.
> Heat Gun or Hairdryer.

INSTALLATION VIDEOS

For installation process and instructions, refer to the Installation Videos on the Hep Desk pages of our website, www.signaturecd.com.