


BLINKER-HALTER

Indicator bracket | Support d'indicateur | Soporte del indicador | Staffetta indicatore

Art.-Nr: 38981-632



LEGENDE / Key / file Légende

- Anbau Tipp**
Fitting tip
Astuce de montage
- Achtung**
Attention
Attention
- Vergrößerung**
Magnification
Grossissement
- Montagepaste**
Fitting lubricant
Lubrifiant de montage

- Schraube**
Screw
Vis
- Schraubensicherung**
Thread locking fluid
Freinfilets
- Drehmoment**
Torque
Torque
- Reiniger**
Cleaner
Nettoyant


#	Bauteil component composant	DE Die Farben der Abbildungen dienen nur der Veranschaulichung. EN The colors are for illustrating purposes only. FR Les couleurs utilisées sont à titre indicatif seulement.	DIN	ISO	Menge quantity quantité
1	Halter / Bracket				1
2	Schraubensicherung / Thread locking fluid				1



Optional: Blinker 36342-XXX und 44109-100 Blinker Adapter-Kabel.
Optional: Turn signals 36342-XXX and 44109-100 Turn signal adapter cable.
En option : clignotants 36342-XXX et 44109-100 Câble adaptateur pour clignotants.

29.08.2025


1



Blinker und Halter vormontieren.

Pre-assemble turn signals and brackets.

Pré-assembler les clignotants et les supports.



Schrauben M5x16 sind Bestandteil des Heckabschlusses 44131-XXX.

M5x16 screws are part of rear closure 44131-XXX.

Les vis M5x16 font partie du capuchon arrière 44131-XXX.

